




SYMPHONY SLEEPSENSE® APP USER GUIDE 1/12 (WITH SLEEPSENSE® ACCESSORY)


App Setup

- You should first download the Symphony SleepSense® app on the Apple or Google Play Store.
- When you open the app, press "Allow" when the app prompts you to allow Bluetooth.

Sign Up



- Once you enter the app, you will create an account by pressing "Sign Up" at the bottom of the screen. After pressing this, you will see the screen shown above. You can create an account with either your phone number or email. Using a phone number is the default option, but you can use an email address by pressing "Email Sign Up."
- Create a password for your account and enter it into the "New Password" and "Confirm New Password" boxes. Then, press "Continue".
- Only U.S. mobile numbers can be used to register.
- The next page should have a box like the one below, where you can enter the confirmation code sent to the email or phone number you entered.



• After doing so, press the box next to "I have read and agree to the privacy policy" and press "Continue".






SYMPHONY SLEEPSENSE® APP USER GUIDE 2/12 (WITH SLEEPSENSE® ACCESSORY)


Sign In

After creating an account, you will be brought to the sign in screen below. Use the phone number or email you signed up
with by selecting "Phone Sign In" or "Email Sign In" at the top of the screen. Then, enter the password you created when
you signed up and press "Sign In".



Reset Password

• If you need to reset your password, select "Reset Password", which is below the "Password" box on the sign in screen. After selecting this, you will be brought to the screen below.







SYMPHONY SLEEPSENSE® APP USER GUIDE 3/12 (WITH SLEEPSENSE® ACCESSORY)

You should reset your password using the same phone number or email you used to sign up. After entering this, you will
be asked to enter a verification code like the one below.



• After entering the verification code, a confirmation number will be sent to the phone number or email entered. After entering this, you can create a new password and press "Save New Password".

Adding a Device

• Once your account is set up and you have signed in, it will bring you to the screen below.




- None of the features of the app will work without adding a device first.
- · To add a device, follow these steps:
 - Plug in your bed and the sleep monitoring box will automatically enter pairing mode. The light on the sleep monitoring box will begin flashing.
 - After pressing "Add Device," you will be brought to the screens below. The app will search for your bed and after you select the bed to connect to, it will prompt you to select the type of bed you have.
 - Your SleepSense® enabled bed will be titled "SleepBT," followed by a series of numbers. Note: You will not connect to devices named "Smartbed" as seen in the picture below, because those types of beds are not able to utilize the SleepSense®.





SYMPHONY SLEEPSENSE® APP USER GUIDE 4/12 (WITH SLEEPSENSE® ACCESSORY)



• When the device's name pops up, press it and your device will be paired. You will then be given an option to name your device, as seen below.




• When your bed is connected, the screen will indicate that the device was added successfully, and the light on the sleep monitoring box will stop flashing.






SYMPHONY SLEEPSENSE® APP USER GUIDE 5/12 (WITH SLEEPSENSE® ACCESSORY)

Device List



- You can check device info, add a new device, and reconnect/disconnect a device in the "Device List," which can be accessed by pressing the bed icon in the upper left corner of the "Remote" page.
 Press the gear icon near the lower right corner of each device you add to the list to check for updates on your
- Press the gear icon near the lower right corner of each device you add to the list to check for updates on your device. If an update is available, the word "New" will appear in the right side of the "Version" box. Press "New" to update the device.

• If you accidentally add the wrong type of device, you can press the gear icon on the device to delete it and add the correct one, as seen below.








SYMPHONY SLEEPSENSE® APP USER GUIDE 6/12 (WITH SLEEPSENSE® ACCESSORY)


App Functions (With SleepSense®): Overview



- The "Overview" page provides information tracked by the SleepSense®. This includes your heart rate, breathing rate, and body movement.
- When the SleepSense® is functioning normally, it will track and display all sleep data. When you are not in bed or in "Privacy Mode" (see "Settings"), new sleep data will not be tracked, and no data will be displayed.

Report













SYMPHONY SLEEPSENSE® APP USER GUIDE 7/12 (WITH SLEEPSENSE® ACCESSORY)

- The "Report" page can be accessed by pressing "View Report" near the bottom of the "Overview" page or by pressing "Report" near the bottom of the screen.
- Specific sleep data is displayed with a variety of charts, as seen above:
 - Deep Sleep, Light Sleep, and Awake Time are displayed in a pie chart.
 - Your heart rate, breathing, snoring, and body motion are displayed in line charts.
 - Your sleep score is displayed as a number. Based on how high or low the number is, the app will give you suggestions on how to improve your sleep. The better your sleep, the higher the score will be.
- This data can be filtered to view data collected on specific days, weeks, or months. You can choose these filters by pressing the "Day," "Week," or "Month" tabs near the top of the screen. To view past days, weeks, or months, press the drop-down menu above the first chart.
- For any days where data is not recorded, zeroes will be in place of where data is displayed.

Remote: Position

- The model of bed you have is shown at the very top of the screen. In the "Position" tab, you can adjust your bed according to its features.
- Features will vary depending on the bed's model, and the differences are shown in the table below.

Bases	Adjustable Features
ES500	Head/Foot/Elevation*
ES600	Head/Foot/Lumbar/Elevation*
ES700	Head/Foot/Lumbar/Wall Hugger/Elevation*
SS300	Head/Foot/Elevation*
SS600	Head/Foot/Lumbar/Wall hugger/Elevation*
ST800	Head/Foot/Elevation*
400E	Head/Foot/Elevation*
500E	Head/Foot/Lumbar/Elevation*
600E	Head/Foot/Elevation*

^{*}Elevation feature requires a separate purchase of an Elevation Kit.












SYMPHONY SLEEPSENSE® APP USER GUIDE 8/12 (WITH SLEEPSENSE® ACCESSORY)

- On most bed models, you can save up to two positions by adjusting the bed to a desired position and holding down
 either of the buttons below "Memory Positions" for 5-6 seconds. You can save one position to both buttons. After doing
 this, if you adjust your bed into any other position, the "Memory Positions" buttons will return you to the positions saved
 on either button.
- Under "Pre-programmed positions," there are three options to choose from. "Flat" returns your bed to a flat position if it is adjusted, "ZG" will put you in the zero-gravity position raising the head and foot, and "Anti-Snore" raises the upper portion of the bed slightly (around 5-10 degrees) to reduce snoring. Additionally, "Toggle Underbed Light On/Off" turns a light on under your bed, should you need it.
- This page also includes an icon in the top right corner of the screen that enables you to use voice control with your bed. On this screen, if you press the icon next to each prompt (Head Down, Foot Down, Elevation Down, ZG, etc.), it will add a command for Siri to follow. You can adjust what you say for Siri to perform these commands as well after you press the icon next to each command. Enabling "Listen for Hey Siri" in your device's "Siri and Search" settings will allow you to use the commands without picking up your phone to activate Siri. Simply say "Hey Siri." Note: This feature is currently only supported by Apple devices.

Massage



- The "Massage" tab seen in the image above allows you to set a timer for how long the massage lasts, adjust the intensity of the massage, and switch massage vibration modes when the user presses "Massage On" near the bottom of the screen.
- Switching between these options can be done by pressing each different circle in each category. To turn the "Massage" function off, press the "Massage Off" button.
- If you cycle all the way through the "Timer" settings (by pressing it one more time when you reach the third circle), it will deactivate the time set for the massage, and turn the massage off.
- In the "Mode" section, the vibration frequency/speed can be increased. The leftmost button is the lowest setting, and the rightmost button is the highest setting.





SYMPHONY SLEEPSENSE® APP USER GUIDE 9/12 (WITH SLEEPSENSE® ACCESSORY)

Alarm



- The "Alarm" tab seen in the image above allows you to set an alarm by swiping the time selector, which is automatically at the current time by default.
- Below the time selector, there is an optional subsection to select a day of the week to repeat the alarm. Once selected, the white border surrounding the weekday will turn yellow.
- Note: Your selection of "Wake Up Types" will vary depending on which model of bed you have. In the "Wake Up Type" subsection, users can choose how they would like to be woken up. "ZG" will put you in the zero-gravity position, "Flat" will bring your bed to the flat position if it is not flat when you sleep, "Memory A" and "Memory B" will adjust it to the preprogrammed positions you can set in the "Positions" tab (see instructions above), and "Massage" will turn on the vibration function. The Alarm can be turned on and off by selecting the "Turn On" box near the bottom of the "Alarm" tab. If you choose "Massage" as a "Wake Up Type", it must be turned off in the "Massage" tab.





SYMPHONY SLEEPSENSE® APP USER GUIDE 10/12 (WITH SLEEPSENSE® ACCESSORY)

Sleep Control



• The "Sleep Control" page is a music player to help improve sleep quality with a variety of sound and music to choose from. You can choose from many different types of white noise or instrumental music.




• When you select a sound or music, a screen like the one above will appear. From here, you can pause, skip, repeat, or shuffle sounds or music based on the category you choose.





SYMPHONY SLEEPSENSE® APP USER GUIDE 11/12 (WITH SLEEPSENSE® ACCESSORY)

Settings



- You can access the "Settings" screen at any time by pressing the gear icon sleep Control" page.
- "Child Mode" disables the "Remote" page and turns off all movement functions of the bed. This can be enabled or disabled by pressing the slider to the right of "Child Mode." If enabled, the message below will display on the "Remote" page.



- "Automatic Reconnection" is on by default and is enabled so each time you enter the app you can adjust your bed without reconnecting to it.
- If you wish to sign in to a different account, you can press "Log Out". If you wish to delete your account and its data entirely, you can press "Account Deletion".
- With the SleepSense® connected you have access to two unique settings, "Privacy Mode" and "Anti-Snoring Intervention".





SYMPHONY SLEEPSENSE® APP USER GUIDE 12/12 (WITH SLEEPSENSE® ACCESSORY)

- If enabled, "Privacy Mode" disables the recording of sleep data. The message "Privacy mode, no data" will display on the "Overview" page. This can be enabled or disabled by pressing the slider to the right of "Privacy Mode".
- If enabled, "Anti-Snoring Intervention" can raise or elevate the base if there are 3 or more snoring signals within 5 minutes. The raising height can be selected by the user on the app. If snoring is detected, it will rise once, and if it is continuously detected, it will rise again, up to 3 times. If snoring is no longer detected after raising, then the bed will maintain the current height. If snoring is still detected after fully rising, the bed will gradually lower until flat. The antisnore cycle will start over up to 3 times. If snoring is still detected after 3 complete cycles, the anti-snore program will not continue.
- To enable this, press "Anti Snoring Intervention" and then press the slider to the right of "Set up Anti Snore Intervention" on the screen below.



There are three levels that determine how much the bed will raise the head or elevate upon sensing snoring, which
include low, medium, and high. As seen in the images below, these options can be demonstrated by pressing
"Demonstration", which will go through the low, medium, and high settings for the "Head" or "Elevation" over a short
period of time, and then return the bed to a flat position. You can set up one of the options to occur when snoring is
sensed by pressing "Set Up".

